MYSTIC CLASSIC MOTORIZED SCREEN INSTRUCTIONS TO REPLACE SCREEN PANEL

You should have received the following replacement parts:

- 1. Replacement Mystic screen panel;
- 2. These "Mystic Classic Motorized Screen Instructions to Replace Screen Panel";
- 3. A copy of the "Mystic Motorized Screens Installation Instructions".

BEFORE BEGINNING THE SCREEN PANEL REPLACEMENT PROCEDURE, BE SURE TO READ THESE INSTRUCTIONS CAREFULLY AND COMPLETELY.

- (i) using the remote, raise the screen panel to its upper limit; remove the hood cover;
- (ii) simultaneously lift both ends of the bottom bar out of the inner side rail; let the bottom bar hang down freely in the front of the side rails;
- (iii) using the remote lower the screen panel sufficiently to allow you to slide the bottom bar to the side and off the bottom zipper of the screen panel (NOTE: the front of the bottom bar is rounded and the back is flat; the Mystic logo is on the front of the bottom bar);
- (iv) using the remote raise the screen panel back to its upper limit;
- (v) disconnect the power; remove the electrical plug and free the power cord. Carefully, pull the power cord so that it is hanging freely;
- (vi) remove the cotter pin that secures the motor to the motor side end-cap of the canister,
- (vii) while firmly holding the screen tube, push sideways to compress the spring on the idler end. This will free the motor from the motor bracket so that the tube can be removed from the canister along with power cord;
- (viii) place the screen roll on a large, clean, flat surface; unroll the screen panel; do not remove the screen panel from the tube; note the direction in which you are unrolling the screen panel so that you will re-roll the screen panel on the tube in the reverse manner; use a Sharpie to mark the channel on the motor tube in which the top zipper is installed;
- (ix) lay the REPLACEMENT SCREEN PANEL on top of the existing screen panel and align the zippers; gussets to match the existing screen panel (NOTE: the bottom of the screen panel is identified by the 2 reinforcing gussets at each corner and the gussets should be on the same side of the replacement screen panel as it is on the existing screen);
- (x) slide the motor tube off the top zippers of the existing screen panel;
- (xi) slide the motor tube on to the top zipper of the REPLACEMENT SCREEN PANEL so that the top zipper is in the same channel on the motor tube that you marked in step (viii) above and the motor is on the same side of the replacement screen as it was on the existing screen panel;
- (xii) roll the screen panel tightly back on to the motor tube (NOTE: the replacement screen panel should be falling off the back of the motor tube);

You may now proceed normally with the installation of the unit beginning on Step 9 of the Installation Instructions. You may need to reprogram the limits of the motor using the limit adjustment tool and remote. Follow the remote and motor programing instructions. Adjust the lower limit first then adjust the upper limit.

FOR ADDITIONAL ASSISTANCE CALL 678-926-9700